

409 Hutt Rd, Lower Hutt Wellington 5010 PO Box 38 453, Wellington Mail Centre 5045

Freephone: 0800 587 0400, Email: sales@colorex.co.nz

www.colorex.co.nz

Wall Sander + Vacuum Instructions

Safety First:

Please ensure these instructions are available to anyone using this piece of equipment.

If this machine is used at a commercial worksite give these instructions to the site supervisor so that the information is readily available to all users.

Required Safety Equipment:

- Ear Muffs
- Safety Boots
- Safety Goggles



Ensure machines have been electrically tagged and are up to date

Start Up Procedure:

- 1. Plug Vacuum Unit into power supply
- 2. Plug Sander Unit into auxiliary socket located on head of vacuum unit
- 3. Plug sander dust extraction hose into the vacuum unit
- 4. Turn Vac control onto 'A' this means vac unit will start up as soon as sander is switched on
- 5. Place sanding disc on sanding unit
- 6. Machine is ready to use

Operating:

- Ensure personal protection equipment is being used
- Turn machine on and set desired speed of sander
- Sand areas to be sanded by moving sanding head along the surface do not put undue pressure on the sanding machine
- Use appropriate grit disc to achieve the desired outcome
- Check Vacuum unit regularly to ensure unit not getting too full.



DISCLAIMER

The manufacturers or supplier will not accept liability for injury or damage resulting from product failure due to misuses, alteration, lack of reasonable care, lack of adequate training, use not listed under these instructions or any other failure not related to defects in materials or manufacture.

